



Clamp holder/receiver

Product code: Clamp01

Overview

The clamp holder/receiver is used to attach the Skipper XS unit and/or tape end to angular surfaces such as door frames, work surfaces and racking. Simply position the clamp in place and turn the screw to tighten. The clamp holder/receiver can be positioned either horizontally or vertically depending on the desired application.

Key selling points

- Holds the Skipper XS unit via its connector points or receives any Skipper tape end clip
- Perfect for door frames, worktops and racking

Key features

- Has an adjustable connector slot which allows it to connect both horizontally and vertically
- Simply adjust the lower clamp up and down the rail to fit the desired surface
- Soft pads to prevent scratching to surfaces

Product Specifications

Width: 140mm 5.5"	Height: 233mm 8.8"
Depth: 103mm 4.1"	Weight: 205g 7.2oz



Attach the Skipper XS unit to the clamp holder/receiver via one of its connector points.

Product FAQs

Q. Does the clamp holder/receiver work with standard Skipper units?

A. The clamp has a connector slot which allows it to receive tape end clips from both the standard Skipper units and Skipper XS units. It cannot be used to hold a standard Skipper unit, but will hold the Skipper XS unit.

Q. What is the widest surface I can attach the clamp to?

A. The clamp holder/receiver will attach to a surface up to 97mm wide.