



Wall support bracket

Product code: W/Support01

Overview

The wall support brackets hold the Skipper unit in place without the need for cones or posts. Unlike the magnetic version, the wall support brackets are intended for permanent/semi-permanent fixture. Simply screw the bracket into the desired position, then click the Skipper unit into place on the bracket (use the orange locking clip to locate into the four corresponding holes on the Skipper).

Key selling points

- Attach a Skipper unit to a wall without having to use a cone or post
- Holds the bracket securely in place. Designed for permanent or semi-permanent fixture.

Key features

- Locking clip which corresponds to the holes on the Skipper unit. Simply squeeze the clip to quickly release the Skipper unit



The Skipper unit simply clicks into place.



Product Specifications

Width: 124mm 4.9"	Height: 168mm 6.6"
Depth: 130mm 5.1"	Weight: 170g 6oz

Product FAQs

Q. What type of screws should I use?

A. We recommend using a screw and roll plug for the chosen surface. The screw head should be at least 10mm in diameter. Fasten tightly with a screwdriver until the bracket is secure. We also recommend using a washer to protect the bracket.